

## Compatibility of DVD Players with Recorded DVD Discs

The capitalized results are from Memorex tests; lower case results are from anecdotal reports. Many factors will determine compatibility, including the legality of the recorded files, the quality of the recorded medium, and whether or not the player could read to the outer edge of the disc, an area not often fully tested.

manufacturer	model	DVD-R	DVD-RW	DVD+R	DVD+RW	note	
Aiwa	CSDDVMIS	no					
	DV3000				yes		
	XD-DV170	no	yes	yes	yes		
	XDDV 290	yes					
	XDDV 370	yes	no		yes		
	XDDV 380			yes	yes		
Alpine	DHA S 680			yes	yes		
Apex	AD 500B	yes	yes				
	AD 660	yes	yes		yes		
	AD 703	yes					
	AD 500A	no					
	AD 500B	no					
	AD 600A	no		yes			
	AD 660	yes		yes	yes		
	AD 730	yes		yes	yes		
	AD 800			yes	yes		
	AD 1200	yes			yes		
	AD 1500	yes		yes	yes		
	AD 3201	yes			yes		
	Afreedy	LD-2060	no				
	Arcam	DV 27				yes	
Audiovox	DVD 31AAST	NO	NO		NO	home system	
BBK	BBK 918				yes		
	BBK 919PS				yes		
	BBK 921D				yes		
	BBK 928				yes		
	BBK 931K				yes		
	DVD AB 907R			yes	yes		
Clarion	VS718				yes		
Daewoo	DVG-3000N	yes	yes		yes		

manufacturer	model	DVD-R	DVD-RW	DVD+R	DVD+RW	note
Denon	ADV 700			yes		
	DVD 800				yes	
	DVD 800N				yes	
	DVD 1000	yes			no	
	DVD 100N				yes	
	DVD 1500	no				
	DVD 1600				yes	
	DVD 1800				no	
	DVD 2800				no	
	DVD 2800N				yes	
	DVD 3000	yes				
	DVD 3300	yes		yes	yes	
	DVM 3700	yes				
Emerson	DVD 2000	yes				
Ferguson	DVD 400			yes	yes	
Finlux	DVD 410				yes	
	DVD 510				yes	
	CTW2827TNDVDC			yes	yes	
Fisher	DVD-S1100				yes	
Funai	F 2000				yes	
	F 2001			yes	yes	
	F 500P			yes	yes	
	DVD WR1			yes	yes	
GE	1101p	yes	yes		yes	
	1106RB				no	
	1401P			yes		
Go! Video	DVP 850				yes	
	DVS 3000	no			yes	
	DVR 4000	YES	YES		YES	DVD/VHS player/recorder
	DVR 5000	yes			yes	
Grundig	GDV 110				yes	
	GDV 130				yes	
	GDV 211GB				yes	
	GDV 5100				yes	
Harmon Kardon	DVD 1				yes	
	DVD 5	yes				5-disc changer

manufacturer	model	DVD-R	DVD-RW	DVD+R	DVD+RW	note
Hitachi	DVD 50	yes	yes	yes	yes	
	DVD W1				yes	
	DVP 250				yes	
	DVP 303				yes	
	DV-B305D	yes		yes	yes	
	DVP-305U	yes		yes	yes	
	DVP-315U	yes	yes	yes	yes	
	DVP 400			yes	yes	
	DVP 415			yes		
	DVP 505				yes	
	DV RP100				yes	
	DVW1	no				
	GD 3000	no	no			
	GD 5000	no	no			
	GVD 305	no	no			
JVC	HTD K150				yes	
	TH A 5R				no	
	TH A 7R				no	
	XV 500				yes	
	XV 501	no	no			
	XV 505 GD			yes	no	
	XV 511				yes	
	XV 511 BK	yes				
	XV 515 GD			yes	yes	
	XV 522				no	
	XV 523	no	no		no	
	XV 523 GD			yes	no	
	XV 525			yes		
	XV 540				yes	
	XV 565	no	no			
	XV 600				yes	
	XVD 701	no	no			
	XVD 723	yes			yes	
	XVE 100				yes	
	XV F 80BK				no	
XV F 85GD			yes	yes		

manufacturer	model	DVD-R	DVD-RW	DVD+R	DVD+RW	note
	XV FA 95				yes	
	XV FA 95GD			yes	yes	
	XV 1000	no	no			
	XV-DV55	yes				
	XV LTR 1				yes	
	XVM 555			yes	no	
	XVM 567	yes			no	3-disc changer
	XV-S 40			yes		
	XV-S40BK	yes				
	XV-SV40BK				yes	
	XV-S42			yes	yes	
	XV-S45				no	
	XV-S60BK	yes		yes		
	XV-S62			yes		
	XV-S65			yes	yes	
	XV-SA65GD	YES	NO			
	XV-SA70BK	yes		yes	no	
	XV-SA72			yes		
	XV-SA75GD	YES	NO	yes	no	
	XV-S500			yes		
	XV-S502			yes		
	XV-S45	yes				
	XFA-95GD	YES	NO			carousel
Kenwood	DV 402	yes	no			
	DV 403	yes	no			
	DVCL85V	yes			yes	
	DVF 3020				yes	
	DVF 3530				yes	
	DVF 3530S			yes	yes	
	DVF 5020			yes	yes	
	DVF 5020S				yes	
	XD DV 9				yes	
KLH	DVD 33				no	
	DVD 1000	yes	no			
	DAV 5022				yes	
Konka	KD 1800U1	yes			yes	

manufacturer	model	DVD-R	DVD-RW	DVD+R	DVD+RW	note
Lasonic	DVD 2000				yes	
	DVD 2100				no	
LG	DVD 4950				no	
	DVD 5500N				yes	
	DVD 5812N				yes	
	DVP HI 2			yes	yes	
Luxman	DVD 470				yes	
Magnavox	DVD 609	YES	YES		YES	
	DVD 611	YES	YES		YES	
	DVD 701	yes				conflicts with Philips player report
	DVD 711	yes				conflicts with Philips player report
Marantz	DV 17			yes	yes	
	DV 3100	some			yes	
	DV 4100				yes	
	DV 4200			yes	yes	
	DV 6200			yes	yes	
	DV 7010			yes	yes	
	DV 18 MKII				yes	
	ER 3000				yes	
Memorex	MVD 2026	YES	YES		YES	
	MVD2027	YES	NO		NO	
Microsoft	Xbox			yes	yes	
Mintek	DVD 1600			yes		
	DVD 2110	YES	YES	yes	YES	
	DVD 2580	YES	YES		YES	
Mitsubishi	DJ P 200			yes	yes	
	DJ P 500			yes	yes	
	DD 2000	no	no			
	DD 3000	no	no			
	DD 4001	no	no			
	DD 4020	yes			yes	
	DVD 6020			yes	yes	
	DD 6600	yes				
	DVD 8020				yes	
Mustek	V 520				yes	
NAD	Auro 9006DD				yes	

manufacturer	model	DVD-R	DVD-RW	DVD+R	DVD+RW	note
	T 550				yes	
Nakamichi	DVD 9000				yes	
Onkyo	DVC-600	yes			yes	
	DVC-601	yes	no			
	DV L 5			yes	yes	
	DV S 353			yes		
	DV S 525			yes	yes	
	DV S 757			yes	yes	
	DV S 939				yes	
Oritron	DVD 100	yes		yes	yes	
	DVD 200	yes		yes	yes	
	DVD 400	yes				
	DVD 600	yes				
	DVD 650	YES	YES		YES	
	DVD 1030			yes	yes	
Panasonic	CT 27 DC50	yes				
	DMR-E10	yes				
	DMR-E20	YES	YES	NO	NO	DVD-RAM and DVD-R set-top recorder
	DVD A7	yes		yes		
	DVD A7D				yes	
	DVD A10	yes		yes	yes	
	DVD A100	yes		yes	yes	
	DVD A110	no	no	yes	no	
	DVD A115			yes	no	
	DVD A120	yes/no	no	yes	yes	
	DVD A300	yes		yes	no	
	DVD A310	yes		yes	no	
	DVD A350				no	
	DVD A360				yes	
	DVD A470				yes	
	DVD A560			yes	no	
	DVD A770			yes		
	DVD C 220D			yes	yes	
	DVD CV 35			yes	no	
	DVD-CV50	yes/no	no			conflicting reports; 5-disc changer
	DVD-CV51	YES	YES		YES	5-disc changer

manufacturer	model	DVD-R	DVD-RW	DVD+R	DVD+RW	note
	DVD-K520	yes				
	DVD-LA 95				yes	
	DVD_LV 50				no	
	DVD LV 60			yes	yes	
	DVD-L 10D	yes				portable
	DVD-L 110	yes				portable
	DVD-L 50D	yes				portable
	DVD PV 55			yes	no	
	DVD R 31				yes	
	DVD RA 60			yes		
	DVD RA 61				yes	
	DVD RP 56			yes	yes	
	DVD RP 91			yes	yes	
	DVD RP 91K				yes	
	DVD RV20	yes			no	
	DVD-RV26	YES	YES		YES	
	DVD RV30	yes		yes	no	
	DVD RV31	YES	YES	yes	YES	
	DVD RV32			yes	no	
	DV RV40			yes	no	
	DVD-RV45KU-5	yes				
	DVD RV55	yes				
	DVD RV56	YES	YES		YES	
	DVD RV65	yes				
	DVD RV70			yes	no	
	DVD RV80	yes				
	DVD X 410				no	
	DVD XP30			yes	yes	
	DVDT2000	yes				
	PV-D4741	yes			yes	
	PV-D4761	yes			yes	
	PV-D M2791				no	
	Q SL GC 10			yes		
	SA HT 70				yes	
	SA HT 80			yes	yes	
	SA HT 290			yes	yes	

manufacturer	model	DVD-R	DVD-RW	DVD+R	DVD+RW	note
	TH15DT2	yes				
Philips	XV LV57				yes	
	DVD 621	YES	YES		YES	
	DVD 701	no	no			conflicts with Magnavox player report
	DVD 711	yes/no	no			
	DVD 170	no	no			
	DVD 400 AT	no	no	yes	yes	
	DVD 404	no	no			
	DVD 570M				no	
	DVD 580				yes	
	DVD 611			yes	yes	
	DVD 612				yes	
	DVD 621				yes	
	DVD 622	yes	yes		yes	
	DVD 701			yes	yes	
	DVD 702			yes	yes	
	DVD 703				yes	
	DVD 704			yes	yes	
	DVD 705				no	
	DVD 710				yes	
	DVD 711			yes	yes	
	DVD 712				yes	
	DVD 712AT21	yes			yes	
	DVD 714				yes	
	DVD 721K				yes	
	DVD 722				yes	
	DVD 730				no	
	DVD 732K				yes	
	DVD 733K				yes	
	DVD 750			yes	yes	
	DVD 751	no	no	yes	yes	
	DVD 752				yes	
	DVD 756				yes	
	DVD 761				yes	
	DVD 762			yes	yes	
	DVD 782	no	no	yes	no	5-disc changer

manufacturer	model	DVD-R	DVD-RW	DVD+R	DVD+RW	note
	DVD 820				no	
	DVD 825AT	no	no	yes	no	
	DVD 835			yes	yes	
	DVD 850AT	no	no			
	DVD 870				yes	
	DVD 870L				yes	
	DVD 930				no	
	DVD 941	no			yes	
	DVD 950	no	no	yes	yes	
	DVD 951				yes	
	DVD 952				yes	
	DVD 952K				yes	
	DVD 953			yes	yes	
	DVD 953AT21	yes		yes	yes	
	DVD 956	yes			yes	
	DVD 956K				yes	
	DVD 957				yes	
	DVD 958				yes	
	DVD 972C	yes				
	DVD 1010				yes	
	DVD Q30				yes	
	DVD Q40				yes	
	DVD Q50	yes	yes	yes	yes	
	DVDR 980			yes	yes	
	DVDR 985			yes	yes	
	DVDR1000	yes	yes	yes	yes	
	ProDVD 160				no	
	SACD 962				yes	
	SACD 1000				yes	
Pioneer	AVSYS 8 DVD				yes	
	DV 7	yes	yes			
	DV233				y	
	DV 301	yes				
	DV 333	yes	yes		yes	
	DV 341	YES	YES		YES	
	DV 343	yes	yes		yes	

manufacturer	model	DVD-R	DVD-RW	DVD+R	DVD+RW	note
	DV 414	yes				
	DV 414	yes				
	DV 434	YES	YES	YES	YES	
	DV 440	YES	YES		YES	
	DV 444	yes	yes		yes	
	DV 503	yes	yes			5-disc changer
	DV 505	yes	yes	yes	yes	
	DV 515	yes	yes			
	DV 525	yes	yes	yes	yes	
	DV 530				yes	
	DV 535	yes	yes	yes	yes	
	DV 545	yes	yes	yes	yes	
	DV 606D	yes			yes	
	DV 626	yes	yes	yes	yes	
	DV 626D			yes	yes	
	DV 636D	yes	yes	yes	yes	
	DV 717			yes	yes	
	DV 3300			yes	yes	
	DV 3500				yes	
	DV AX10	yes	yes		yes	
	DV C 36				yes	
	DV C 302D			yes	yes	
	DV C503	yes			yes	5-disc changer
	DV DR 535				yes	
	DV DR 737				yes	
	DVD V555			yes		
	DV F 727				yes	
	DV K102	yes	yes			
	DV K301C	yes	yes			
	DV K800	yes	yes			
	DV K900	yes	yes			
	DV K1000	yes	yes			
	DV L9	yes	yes		yes	
	DV L10				yes	
	DVL90	some				
	DV L414				yes	

manufacturer	model	DVD-R	DVD-RW	DVD+R	DVD+RW	note
	DVL 700	yes			yes	
	DVL 909	yes	yes	yes		
	DVL 919	yes	yes	yes	yes	
	DVL 919E			yes	yes	
	DVL H9	yes	yes		yes	
	DVL K88	yes	yes			
	DVR 1000	yes				set-top recorders
	DVR 2000	yes			yes	set-top recorders
	DVR 7000	yes	yes		yes	
	DV S5	yes	yes			
	DV S6D	yes	yes		yes	
	DV S9	yes	yes			
	DV S10A	yes	yes	yes	yes	
	DV S646A			yes	yes	
	DV S737	yes	yes	yes	yes	
	DV S747A			yes	yes	
	DV S838A	yes	yes	yes	yes	
	Elite DVF 07	yes				
	Elite DV 05	yes				
	Elite DV 500	yes				
	Elite DV 505	yes	yes			
	Elite DV 525	yes	yes			
	Elite DV 606D	yes				
	HTZ 7	yes	yes			
	HTZ 50DV				yes	
	HTZ 55DV	yes	yes		yes	
	HTZ 330V			yes	yes	
	PDV 01	yes	yes			
	PDV 10	yes	yes		yes	
	PDV 10 SW	yes	yes			
	PDV 20	yes	yes	yes	yes	
	PDV LC01	yes	yes			
	PDV LC10	yes	yes		yes	
	PDV LC20TV	yes	yes		yes	
	XDV-P9	yes	yes			player for vehicles
	SDV-P7	yes	yes			player for vehicles

manufacturer	model	DVD-R	DVD-RW	DVD+R	DVD+RW	note	
Proscan	AVX-P7DV	yes	yes			player for vehicles	
	AVIC-H09	yes	yes			car navigation	
	DVR-1000	yes	yes			recorder; will not record on general use DVD-R	
	DVR-2000	yes	yes			recorder	
	P 8610P	yes					
	P 860Z	yes					
	PS 868OZ	yes			yes	yes	
Raite	PS 8682P			yes	yes		
	AV 716				yes		
RCA	RDP 715	yes			yes		
	RC 5200	yes					
	RC 52152	yes					
	RC 5215P	yes			yes		
	RC 5220P	yes			yes		
	RC 5225P	yes					
	RC 5230Z				yes		
	RC 5231Z				yes		
	RC 5240	YES	NO		YES		
	RC 5240P			yes			
	RC 5910	no	no				
	RC 6001P				yes		
	Sampo	DVE 520	no	no			
		DVE 611			yes	yes	
DVE 620					no		
Samsung	DVD 301				yes		
	DVD 511	yes			yes		
	DVD 611	yes			yes		
	DVD 618J			yes	no		
	DVD 709	no					
	DVD 709/XAA			yes	yes		
	DVD 711				yes		
	DVD 716K			yes	no		
	DVD 905	yes		yes	yes		

manufacturer	model	DVD-R	DVD-RW	DVD+R	DVD+RW	note
	DVD 907			yes	no	
	DVD 916K				yes	
	DVD 1000	yes				
	DVDM 30				yes	
	DVDM 101	YES	YES		YES	
	DVDM 105			yes	yes	
	DVDM 208J			yes		
	DVDM 301	YES	NO	yes	YES	
	DVDM 302	yes				
	DVDN 501	YES	NO	yes	YES	carousel; struggled to read DVD-RW
	DVD P 401				yes	
	DVD P 701				yes	
	DVD PT 200				yes	
	DVD S 221			yes	yes	
	DVD S 222			yes		
	DVD V 1000			yes	yes	
	DVD V 2000			yes		
	DVD V 2500				yes	
	SV DVD 1E			yes	yes	
	SV DVD 5J			yes	yes	
Sanyo	DC-AVD8501				yes	
Schaub Lorenz	SL-D4000				yes	
SEG	DVD 2000				yes	
	DVD 2001				yes	
Sharp	DV 740			yes	yes	
	DV 750			yes	yes	
	DV 750U	yes		yes	yes	
	DV 760				yes	
	DV 770U				yes	
	DVL 70TV	some				
	DVL 70U	yes				
	DV L 80				y	
	DV L 90TC				y	
	DVD 330S	yes				
	DVD 600	no	no			
	DVD 739	no	no			

manufacturer	model	DVD-R	DVD-RW	DVD+R	DVD+RW	note
	DVD 709/XAA	no	no			
	DVD 839	no	no			
	DV NC 55			yes	yes	
	DV NC 550			yes	yes	
	DV S 1			yes		
	DV S200	some				
Shinco	DV SF20	yes		yes	yes	
	DVD 2120				yes	
	DVD 2200			yes		
	DVD 8320			yes		
	DVD 858PS			yes		
	DVD 860			yes		
Shinsonic	DVD-160			yes	yes	
Skyworth	1050P			yes		
	DVD 810			yes		
SMC	DVD 330S	yes			yes	
Sony	cv	yes				
	DAV C700				yes	
	DAV S300				yes	
	DAV S500			yes	yes	
	DAV S800				yes	
	Disc Browser 200				yes	
	DVP 850D				yes	
	DVP C600	yes				
	DVP C650D	yes		yes	yes	
	DVP C660	yes		yes	yes	5-disc changer
	DVP C670D	yes			yes	5-disc changer
	DVP CX850D	yes				200-disc carousel
	DVP CX860	yes		yes	yes	2-sided changer; holds 300 discs
	DVP CX 870D	YES	YES		YES	2-sided changer; holds 300 discs
	DVP F5	yes			yes	
	DVP F11				yes	
	DVP F15			yes	yes	
	DVPF21	YES	YES	yes	YES	portable
	DVP FX1	yes		yes	yes	
	DVP K350				y	

manufacturer	model	DVD-R	DVD-RW	DVD+R	DVD+RW	note
	DVP K360			yes		
	DVP K880D				yes	
	DVP N2400D	yes	yes			
	DVO N3300				yes	
	DVPN 600B	YES	YES		YES	
	DVP NC600	yes	yes	yes	yes	
	DVP NC600B				yes	
	DVP NC650B				yes	
	DVP NS300	YES	YES		YES	
	DVP NS315			yes		
	DVP NS400				yes	
	DVP NS400D	YES	YES	yes	YES	
	DVP NS500P				yes	
	DVP NS500V				yes	
	DVP NS600			yes		
	DVP NS700P	YES	YES	yes	YES	
	DVP NS700V			yes		
	DVP NS900V			yes	yes	
	DVP S300	yes	yes			
	DVP S313				yes	
	DVP S313D			yes	yes	
	DVP S315			yes	yes	
	DVP S325			yes	yes	
	DVP S330	yes		yes	yes	
	DVP S335				y	
	DVP S336			yes	y	
	DVP S345				y	
	DVP S350	yes			yes	
	DVP S360	yes	yes	yes	yes	
	DVP S363				yes	
	DVP S500	yes				
	DVP S500D			yes	no	
	DVP S525D			yes	yes	
	DVP S530D			yes	yes	
	DVP S550D	yes		yes	yes	
	DVP S560	yes		yes	yes	

manufacturer	model	DVD-R	DVD-RW	DVD+R	DVD+RW	note
	DVP S560D	yes	yes		yes	
	DVP S570D	yes			yes	
	DVP S715			yes	yes	
	DVP S717D					
	DVP S725					
	DVP S735D					
	DVP S3000	no	no			
	DVP S3000TP	no	no			
	DVP S7000	no	no	yes		
	DVP S7700	yes		yes	yes	
	DVP S9000ES	yes		yes	yes	SACD player also
	DVP 7000	yes				
	DVP 7700	yes				
	DVP 9000	yes				
	PVDV 30	no	yes			
	Playstation 2	yes		yes	no	
	Playstation 2 (30000+)			yes	yes	
	PBD V 30			yes	no	
	RDR A1				yes	
Sylvania	DVL 100A	no	no			
	DVL 500A				no	
	DVL 1000	no	no			
TEAC	DV 3000			yes	yes	
Technics	A10D	yes			yes	
	DVD-A10PP-N	no				
	SA DV250				yes	
Thomson	C3400	yes				
	DTH 3600			yes	yes	
	DTH 5200				yes	
	DTH 5400				yes	
	GE 1101P			yes	yes	
	GE 1105P			yes	yes	
	GE 5803P			yes	yes	
	RC 5215P			yes	yes	
	RC 5220P			yes	yes	
	RC 5320Z			yes	yes	

manufacturer	model	DVD-R	DVD-RW	DVD+R	DVD+RW	note
Toshiba	RC 6000Z			yes	yes	
	MED 300AS	no				
	SD 100 ESMZ				yes	
	SD 110E			yes	yes	
	SD 160L	no			yes	
	SD 200 E				yes	
	SD 220 E			yes	yes	
	SD 1200	yes	no		yes	
	SD 1300			yes	yes	
	SD 1500	yes	no		yes	
	SD 1600	yes			yes	
	SD 1700	YES	YES	yes	NO	displayed "disc error" for DVD+RW
	SD 1900			yes		
	SD 2006	no	no			
	SD 2107U	no	no		no	
	SD 2108U	no	no			
	SD 2109	no	no	yes	yes	
	SD 2150	yes				
	SD 2200	yes		yes	yes	
	SD 2300	yes				
	SD 2700	yes				yes
	SD 2705	YES	NO	yes	YES	carousel; displayed "disc error" for DVD-RW
	SD 2800			yes	yes	
	SD 3000	no	no			
	SD 3006	yes/no	no			
	SD 3107	no	no			
	SD 3109	no	no	yes	yes	
	SD 3110	no	no			
	SD 3205	yes		yes		
	SD 3500			yes	yes	
	SD 3750	YES	YES	yes	YES	
	SD 3755				y	
	SD 4205	yes				
SD 4700	YES	YES	yes	YES		
SD 5000	yes	no				
SD 5109	no	no	yes	yes		

manufacturer	model	DVD-R	DVD-RW	DVD+R	DVD+RW	note
	SD 5500			yes	yes	
	SD 6109C	no	no			
	SD 6200	yes		yes	yes	
	SD 9000	no	no			
	SD 9200	yes	no		yes	
	SD K310	no	no			
	SD K311				yes	
	SD K320N	no	no			
	SD K330			yes	yes	
	SD P1000				no	
	SD V190			yes	yes	
	SD V620	no	no			
Tprogress	ACM 1070				no	
	ACM 5010P				no	
Tredex	TX 8303	yes			no	
VDDV	AD 600A				no	
Victor	DVD D721			yes	yes	
	HR DV1			yes	yes	
	XV-521	some		yes		
	XV 1000			yes	no	
	XV D 9000				yes	
	XV P300			yes		
	XV Z S100S				yes	
X-Wave	1000K				yes	
	B171-L9	no	no		yes	
	LB 900				yes	
Yamaha	DV C 6280				yes	
	DVD-5350				yes	
	DVD-5796	yes				
	DVD C900	no	no			
	DVD C996	yes				
	DVD S510B				yes	
	DVD S1200				yes	
	DVD S510B	no				
	DVD S700	yes				
	DVD S795				yes	

manufacturer	model	DVD-R	DVD-RW	DVD+R	DVD+RW	note
	DVD S796	yes		yes		
Yukai	V 520				some	
Zenith	DA 3520				no	
	DC 596N				no	
	DVB 216				yes	
	DVC 2200	yes			yes	
	DVC 2201	yes	yes		yes	
	DVC 2250	yes				
	DVC 2515	yes				
	DVD 2381				yes	
	DVD 5591				yes	
	DVD S 201			yes		
	IQ DVD 2300	yes/no	no			
Zenix	Z 2000			yes	yes	
	Z 3151			yes	yes	

### Play Compatibility of DVD-Drives with Recorded DVD Discs

manufacturer	model	DVD-R	DVD-RW	DVD+R	DVD+RW	note
HP	dvd 1000i	YES	YES		YES	burner
Panasonic	DMR-E20*	YES	YES	NO	YES	set-top recorder
Pioneer	DVD-ROM DVD 114	yes	yes			
	DVD-ROM DVD 116	yes	yes			
	DVR-S201	yes	yes			burner
	DVR-A03	YES	YES	NO	NO**	burner
	DVR-A04	yes	yes		yes	burner
Ricoh	MP-5125A	YES	YES	YES	YES	
Samsung	DVD-ROM SD-612	NO	NO			DVD drive in Dell computer
Toshiba	DVD-ROM SD-C2302	YES	NO			DVD drive in Dell laptop

\*DMR-E20 can record DVD-Rs, but they do not play on the HP, Pioneer, or Ricoh drives.

\*\*Firmware versions 1.68 do not read DVD+RW; earlier versions do.